

User Manual

MEGAPHONE COPA

Model: 15520



All ABS Body, sturdy yet light weight, Built –in Music or Siren, Clear sound, long range & efficient design, Conveniently located Volume Control & Switch, Recording: 10 seconds.

Specifications:

Item	Mini Megaphone COPA 10W
Model	15520
Material	ABS
Power Source	6x5# "size AA" Cells
Dimensions	ø98 x 155 mm
Power Output	10W
Weight	270g without cells
Voice Range	150m

Operation:

Open the Back Cover by pressing the Open Button.

Insert 6 x 5# "AA" Cells then close the back cover until it locks. Now your megaphone is ready for action.

To activate the megaphone, press the ON/OFF Button on the Back Cover.

Adjust the Volume Control to the desired level without causing any howling or feedback.

Press Music or Siren button to activate music or siren. To switch off the Siren, press the same button again, or press the ON/OFF button.

Press the Record button, say what you want to say 10 seconds, then press the Speaker button, play the recording.